


Brivis Models:

**Contour Series**

**Promina Series**

**Advance Series**

**AD Series**



## Evaporative Air Coolers

Operation Manual

**brivis**  
by Rinnai

This appliance must be installed in accordance with:

- Manufacturer's Installation Instructions
- Current AS/NZS 3000
- Local Regulations and Municipal Building Codes including local OH&S requirements

This appliance must be installed, maintained and removed only by an Authorised Person.

For continued safety of this appliance it must be installed and maintained in accordance with the manufacturer's instructions.



# TABLE OF CONTENTS

<b>Warnings and Important Information</b>	<b>5</b>
Regulatory / Installation / Safety .....	5
Mandatory Inspection Prior to Installation .....	6
Models Covered In This Manual .....	6
<b>Clearances</b>	<b>7</b>
Roof Mounted Evaporative Cooler Positioning .....	7
<b>Evaporative Cooler Operation</b>	<b>8</b>
Introduction .....	8
How Does Your Evaporative Cooling Work? .....	8
Before Operating Your Evaporative Cooler .....	8
The Air Smells A Little Different, Why? .....	9
Start Up .....	9
Shut Down .....	9
On Humid Days .....	9
Ceiling Vent(s) Location .....	9
<b>Networker Wall Control Operation</b>	<b>10</b>
About Your Brivis Networker Wall Control .....	10
Automatic Pre-Wet .....	11
Automatic Operation .....	11
Manual Operation .....	12
Using The Timer .....	12
Setting The Time & Day .....	13
Setting The Cooler To Turn Itself ON .....	13
Setting The Cooler To Turn Itself OFF .....	13
Checking Your Timer Settings .....	13
Coded Messages .....	14
Message Repeating .....	14
Service Notification Message .....	14
Resetting .....	14
Locking The Brivis Networker .....	15
Setting the PIN .....	15
To Lock the Brivis Networker .....	15
To Unlock the Brivis Networker .....	15

**TABLE OF CONTENTS**

Zoning ..... 16

Dual Brivis Networker Operation ..... 16

Batteries ..... 16

**Programmable Control Operation 17**

    Operating Your Programmable Wall Control ..... 17

    Automatic Pre-Wet ..... 17

    Operating Modes ..... 17

    Auto Operation ..... 17

    Getting Started ..... 17

    Benefits of Using in AUTO Mode in Preference to Manual Mode ..... 17

    Manual Operation ..... 18

        Getting Started ..... 18

        Fan and Pump ..... 18

        Fan Only ..... 18

        Pump Only ..... 18

        Using the Timer ..... 18

        Setting the Timer ..... 18

**Manual Wall Control Operation 19**

    Operating Your Manual Wall Control ..... 19

        To run the Cooler ..... 19

        To turn OFF ..... 19

        To tun the Fan for ventilation ..... 19

**Care & Maintenance 20**

    Cooler Service & Maintenance ..... 20

    Save a Service Call ..... 20

    Installation Record ..... 21

    Service Maintenance Schedule ..... 22

**FAQ 23**

**Warranty 26**

**Contacts 32**

# WARNINGS AND IMPORTANT INFORMATION



READ ALL INSTRUCTIONS BEFORE USING THE APPLIANCE.

Failure to carefully read and follow all instructions in this manual can result in equipment malfunction, property damage, personal injury and/or death.

**WARNINGS:** WHEN IGNORED, CAN RESULT IN SERIOUS INJURY OR DEATH.

**CAUTIONS:** WHEN IGNORED, CAN RESULT IN MINOR INJURY OR PRODUCT DAMAGE.

**SHALL / MUST /IMPORTANT:** INDICATES A MANDATORY REQUIREMENT OF THIS MANUAL.

**SHOULD:** INDICATES A RECOMMENDED REQUIREMENT OF THIS MANUAL.

Any deviations from these instructions may, at the discretion of Rinnai, void the warranty. As a result, the customer and/or installer may be charged a fee for product non-warranty related call outs. Also, note that failure to comply with these instructions may preclude Rinnai from being able to service the unit.

**DISCLAIMER:** This document is a guide only. Laws, regulations and industry standards can vary between States and Territories.

Accordingly, this guide **MUST BE** read in conjunction with, and subject to, all laws, regulations and industry standards applicable in the State or Territory in which the products are installed.

You **MUST** ensure that the installation of the products will comply with those laws, regulations and standards, and that the products recommended to customers are fit for the purpose for which they are intended.



## REGULATORY / INSTALLATION / SAFETY

This appliance **SHALL BE** installed in accordance with:

Manufacturer's Installation Instructions.

Current AS/NZS 3000 (electrical codes).

Local Regulations and Municipal Building Codes including local OH&S requirements.

Local water authority regulations

Duct fixing regulations, EPA guidelines and AS HB276-2004 "A Guide to Good Practice"

**ALWAYS** comply with the following precautions to avoid dangerous situations and to ensure optimum performance.

This appliance **MUST BE** installed, maintained and removed by an Authorised Person.

**DO NOT** place any articles on or against this appliance

**DO NOT** use or store flammable materials near this appliance

**DO NOT** spray aerosols in the vicinity of this appliance while it is in operation

**DO NOT** modify this appliance

This appliance is intended to be permanently connected to the water mains and **NOT** to be connected by a hose-set.

If the supply cord is damaged, it **MUST BE** replaced by manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

This appliance is **NOT** intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Children should be supervised to ensure that they **DO NOT** play with the appliance.

Brivis Contour Series & Promina Series evaporative coolers are **NOT** intended for installation in BAL-12.5 to BAL-29 areas.

## WARNINGS AND IMPORTANT INFORMATION



In order to avoid a hazard due to inadvertent resetting of the thermal cut-out, this appliance must not be supplied through an external switching device, such as a timer, or connected to a circuit that is regularly switched on and off by the utility.



### MANDATORY INSPECTION PRIOR TO INSTALLATION

Immediately report any damage or discrepancies to your appliance supplier. This appliance has been inspected and tested at the time of manufacture and packaging, and was released for transportation without known damage. Upon receipt, inspect the exterior for evidence of rough handling in shipment. Ensure that the appliance is labelled correctly for the gas, electrical supply, or other services it is intended to be connected to.

For safety and warranty purposes, appliances that may be damaged or incorrect **MUST NOT** be installed or operated under any circumstances. No responsibility will be accepted for installation or operation of damaged or incorrect appliances. Installation of damaged or incorrect appliances may also contravene local regulations.



### MODELS COVERED IN THIS MANUAL

Brivis Contour Series*	L37	L47	L57	L67	L77	
Brivis Promina Series	P36	P46	P56	P66	P76	
Brivis Advance Series*	F36DS	F46DS	F56DS	F66DS	F76DS	F86DS
Brivis AD Series				AD66D		AD86D
Brivis AD BAL Series			AD56D	AD66D		

\* Brivis Contour and Brivis Advance are fitted with a Motorised Winter-Seal.



### A NOTE ON ILLUSTRATIONS

The illustrations used in this manual are for explanatory purposes only and the shape of your unit may vary slightly from that which is shown in this manual.

# CLEARANCES

## ROOF MOUNTED EVAPORATIVE COOLER POSITIONING

The cooler must be installed in a position that allows for optimal performance and adequate and safe access for service, as per installation guidelines and any applicable regulations.

**Extra service charges may apply for the cost of any equipment or additional labour involved in accessing the cooler if these guidelines are not met.**

These extra charges apply to both product warranty claims, general repairs and service maintenance calls.

REQUIRED CLEARANCES	
Low Profile Units (Sloping Base)	1m on three (3) sides (front and two sides)
Traditional Units (Flat Base)	1m on all four (4) sides

# EVAPORATIVE COOLER OPERATION

## INTRODUCTION

Congratulations on your purchase of a Brivis Cooling system. For you to achieve the performance and efficiency expected from your new cooler, please ensure the installer is a qualified trades person, that the installer has commissioned the unit before you commence operating, and you take the time to read the contents of this manual.

In some Australian States it is mandatory that your cooler installation is issued with a certificate of compliance to guarantee the installation workmanship. Please check with your installer or the local plumbing authority or association. The Brivis cooler is covered by the product warranty as outlined in this manual.

## HOW DOES YOUR EVAPORATIVE COOLING WORK?

The amount of cooling available from any type of cooling system is dependent on the outside weather conditions. Your evaporative cooler works best on hot, dry days. It is essential to provide the required amount of ventilation (for your evaporative cooling system to function properly) by opening windows/doors whenever the cooler is operating. Air is drawn in through the filter pads resulting in 100% fresh cool air entering the home. The movement of this cooled air through your home will draw the heat out of the house, so be sure that doors or windows are open to expel this heat to outside.


Whenever possible start the cooler early to prevent the build up of heat within the house, and on sultry or humid days your cooler may work better with the fan **ONLY** running and the pump turned OFF. Stale air, cigarette smoke and fumes can be quickly cleared and replaced with fresh air by turning the fan to manual mode.

## BEFORE OPERATING YOUR EVAPORATIVE COOLER

Make sure enough window and/or door area is open for the unit to work correctly. The following table gives a guide to the amount of open area required for each model in m<sup>2</sup>, and also gives suggestions on how to provide this.

Brivis Models				Number of average size windows & doors ( <i>suggestions only</i> )	Highest Fan Setting	Lowest Fan Setting
Contour Series	Promina Series	Advance Series	AD Series			
L37	P36	F36DS		One door and a hinged window	1.9 m <sup>2</sup>	1.1 m <sup>2</sup>
L47	P46 P56	F46DS F56DS	AD56D BAL	Three sliding windows or one door & two hinged windows	2.3 m <sup>2</sup>	1.4 m <sup>2</sup>
L57	P66	F66DS	AD66D / BAL	Four sliding windows or one door and four hinged windows	2.8 m <sup>2</sup>	1.7 m <sup>2</sup>
L67	P76	F76DS		Five sliding windows or one door and five hinged windows	3.1 m <sup>2</sup>	1.9 m <sup>2</sup>
L77		F86DS	AD86D	Six sliding windows or one door and six hinged windows	3.4 m <sup>2</sup>	2.1 m <sup>2</sup>


Average ventilation area provided by various openings when fully opened.



**NOTE** You can also choose to have these openings only halfway open. However, the opening will only provide half the amount of ventilation shown and additional ventilation openings would be required.



To cool your whole house, you need windows and / or doors open throughout the house. If you wish to concentrate your cooling to a select area, simply concentrate all the required ventilation in the targeted area (see below).



**NOTE** On hot, windy days, ensure that the windows and /or doors open for ventilation are on the sheltered side of the house.

### THE AIR SMELLS A LITTLE DIFFERENT, WHY?

New Cooling pads can give off a mild odour while they are settling in. This is quite normal, it will dissipate quickly as the new pad is constantly flushed during use.

### START UP

When the cooling is first turned ON, there will normally be a delay before the cool air is delivered from the duct outlets. The delay will vary depending on the model of cooler, but this doesn't mean the cooler is not operating. Most models have pre-programmed function times, to allow time to fill the Cooler's tank with water and/or Pre-wet the filter pads. Brivis Contour Series models have an additional delay to allow time to open the ServoSeal damper. The entire process can take up to 8 minutes before cool air is expected from the duct outlets.

### SHUT DOWN

On Brivis Advance, Brivis Promina, Brivis Contour and Brivis AD (when fitted with optional valve) units, there is also a delay in emptying the water from the Cooler's tank for a period after the unit has turned OFF at the end of use. Brivis Advance, Brivis Promina and Brivis Contour models have an additional pre-programmed tank wash cycle (flush). This washes the tank with clean water at the end of use. At the same time Brivis Contour models will also close the motorised ServoSeal damper, which seals the ducting, reducing drafts. The ServoSeal and flush will occur approx 1 hour after the unit has been turned off.

### ON HUMID DAYS

On days of high humidity your evaporative cooler works best with the fan on high and perhaps the pump switch turned off. If moisture is building up on tiled or hard surface areas, ensure that airflow from the outlets is directed across the ceiling rather than down towards the floor. Also ensure that you have enough windows and/or doors open.


### CEILING VENT(S) LOCATION

Vents should be set up so the air is directed across the ceiling. However, they should not be restrictive and the vents should also be directed to disperse air evenly around the room depending on the location of the vent.

# NETWORKER WALL CONTROL OPERATION

## ABOUT YOUR BRIVIS NETWORKER WALL CONTROL

The Brivis Networker wall control operates the complete cooling system, communicating key information and sensing the temperature. It is an important part of the unit and the following text will explain its operation.




- 1. On/Off Button**  
This is the button to turn the Brivis Networker ON or OFF.
- 2. Function (Fn) Button**  
The function button, when used in conjunction with keys 1 & 2 allows the user to perform specialised functions such as message repeating & Brivis Networker locking. The Fn button also activates the LED backlight.
- 3. Mode (M) Button**  
This button is used to set/change the controller PIN.
- 4. Heartbeat Symbol**  
A flashing heart icon in the bottom right hand corner indicates that the room temperature is being sensed from this Brivis Networker.
- 5. Program (PROG) Button**  
This button is used to set the Brivis Networkers automatic program.
- 6. Auto (AUTO) Button**  
This button allows the user to switch between the Auto Program and the Manual Operation.
- 7. Rotary Dial**  
This Dial is used to change the Cooler settings.
- 8. Variable Keys**  
The keys numbered 1 to 5 (14 to 18) vary their function depending on the program or mode displayed. They will only have a function if text appears on the screen beside the key & a black rectangular box. (Keys used for zoning function may also display an arrow)
- 9. Water Droplets Symbol**  
The two alternating water droplets indicate that the cooler pump is turned on.
- 10. Fan Symbol**  
When the fan is flashing it indicates the unit is in pre-wet mode. When the fan is rotating it indicates the fan is turned on.
- 11. Thermometer / Fan Speed Bar**  
In auto mode the thermometer indicates the set comfort level. In manual mode the thermometer indicates the set fan speed.
- 12. Padlock Symbol**  
The padlock symbol indicates the child proof lock has been set. For more information refer to the section Locking the Brivis Networker.
- 13. Digital Display (LCD screen)**  
Provides you with information about the system. The display shows the current time via a Digital Clock in the top left corner, the Day of the Week on the left-hand side, and the type of Appliance selected at the bottom. The display will also show scrolling messages across the top of the screen. The messages usually relate to a certain action such as cooler Pre-Wet which shows - *"Pre-Wetting cooler pads - Please Wait!"*

### AUTOMATIC PRE-WET

When the Cooler is turned ON, with both the fan and the pump in either Auto or Manual mode, the Cooler will start a Pre-Wet automatically. The Pre-Wet stage ensures the pads are thoroughly wet before the fan starts. This prevents warm air being initially blown into your home and contributes to the effective operation and performance of the Cooler. The Pre-Wet time will vary depending on how long the Cooler has been OFF, and whether it needs to fill the tank prior to operation. During the Pre-Wet the message “Pre-Wetting cooler pads - Please Wait!” will scroll across the top of the display.

### AUTOMATIC OPERATION

In Auto mode the Brivis Networker automatically turns the pump ON or OFF as required and varies the fan speed to maintain your selected “comfort level.”



#### To run the unit in Auto mode, just follow these easy steps:

1. Turn the Brivis Networker on using the ON/OFF button (1).
2. Press the Auto button (6) until “Auto” appears on the screen.
3. Rotate the Rotary dial (7) to set the comfort level you desire (up to have a cooler comfort level and down to have a warmer comfort level) the set comfort level (11) is displayed on the LCD screen (13).




**It will take approximately 8 minutes for the Cooler to complete the pre-wet before the fan will turn on. The next time you return to “Auto” these steps will not be necessary because the Brivis Networker remembers your previous settings.**

#### Benefits of using Brivis coolers in Auto mode in preference to Manual mode

- Power and water consumption varies in relation to the chosen comfort level. This comfort level cannot be as easily maintained in Manual mode.
- In Auto Mode the unit operates only when it is required.
- Enables a set comfort level to be maintained automatically as the outside / inside temperature conditions change.
- It allows you to pre-set the cooler to turn ON early and not let the house build up heat.
- The outlet airflow noise is kept to a minimum, as the fan speed is only as fast as required to maintain the set comfort level. This slower speed also results in more efficient saturation of the Cooler filter pads, and a cooler outlet air temperature.

**MANUAL OPERATION**

Manual operation enables you to control the fan, its speed, and the pump manually.



**To run the Cooler in Manual mode, just follow these steps:**


1. Turn the Bravis Networker on using the ON/OFF button (1).
2. Press the Auto button (6) until “MANUAL” appears on the screen.
3. Press Key 1 (14) to turn the fan on (if the fan symbol (10) is not already on the screen).
4. Press Key 2 (15) to turn the pump on (if the water droplet symbols (9) are not on the screen).
5. Rotate the Rotary dial (7) to set the fan speed level you desire (up to increase the fan speed and down to decrease the fan speed). The set fan speed (11) is displayed on the LCD screen (13). The message “Pre-Wetting cooler pads – Please Wait!” will scroll across the display. It will take approximately 8 minutes for the unit to complete the pre-wet before the fan will turn on.



On days of high humidity the fan may be operated without the pump. To turn the pump OFF press Key 2 (15) and the water droplets (9) will disappear. The next time you return to Manual these steps will not be necessary because the Bravis Networker remembers your previous settings.

**USING THE TIMER**

When the Cooler is operating, you can pre-set a time for the Timer to turn the Cooler OFF. Also, when the Cooler is turned OFF, you can select a time for the Timer to turn it ON automatically. So if you are out for the day you can set the Cooler to come on and cool the house before you return. Before using the timer function you need to firstly set the time and day.





If the pump is going to be used, adequate ventilation (openings) need to be provided to prevent condensation build up.

**SETTING THE TIME & DAY**

1. Ensure the Networker is turned OFF using the ON/OFF button (1).
2. Press Key 5 (18 - Clock) and the screen will display the message “Clock setting mode”, and then the Digital Clock (19) will flash.
3. Use the Rotary Dial (7) to select the right time.
4. Press Key 1 (14 -Day) until the correct day appears e.g. Mon (20).
5. Press Key 5 (18 - Clock) again to save the changes.



If you have dual Brivis Networkers installed, only the Master control has the ability to set the clock time. The Master control can be identified by the word “clock” beside Key 5 (18), while the Brivis Networkers are in the off position.

**SETTING THE COOLER TO TURN ITSELF ON**

1. Press the PROG button (5) and the display will flash ON TIME and the word PROGRAM.
2. Use the Rotary Dial (7) to set the ON TIME (i.e. the time you want the Cooler to come ON).
3. You can change the settings the cooler will run at here.  
*When in Manual mode, use the Rotary Dial (7) to adjust the fan speed and press Key 2 (15) to turn the pump ON or OFF. When in Auto mode, use the Rotary Dial (7) to adjust the comfort level.*
4. Press Key 3 (16 - On Time / Off Time) to activate the Timer.
5. Press the PROG button (5) to exit and save your setting.



The LCD screen (13) displayed On Time (21) to show that an On timer is set. To cancel the Timer press Key 3 (16).

**SETTING THE COOLER TO TURN ITSELF OFF**

1. Ensure the cooler is turned ON.
2. Press the PROG button (5) and the display will flash OFF TIME and the word PROGRAM.
3. Use the Rotary Dial (7) to set the OFF TIME (i.e. the time you want the Cooler to turn OFF).
4. Press Key 3 (16 - On Time / Off Time) to activate the Timer.
5. Press the PROG (5) button to exit and save your setting.



The LCD screen (13) displayed Off Time (22) to show that an Off timer is set. To cancel the Timer press Key 3 (16).

**CHECKING YOUR TIMER SETTINGS**

Once Timer settings are made you can review or cancel them in a number of methods:

The LCD screen (13) displays On Time (21) and or Off Time (22) to show that these timers have been pre-set.

**If you want to check what you’ve done**

Press the PROG button (5) and the pre-set time will flash. You can now make adjustments to your settings if required.

**If you change your mind and want to cancel the function**


Press the Key 3 (16 - On Time / Off Time) and this will cancel the function.

**To exit this setting program**



## NETWORKER WALL CONTROL OPERATION

Press either the ON/OFF button (1) or the PROG button (5). The Bravis Networker remembers the last setting and the next time you select the Timer it will go to that same setting.



### CODED MESSAGES

While the Bravis Networker is operating your system, it is also monitoring and controlling every aspect of the system's performance. If anything unusual occurs, the Bravis Networker will display an error message.

- A message (23) stating "Cooler Fault - E01 Code #?? For assistance call 1300 555 545" will scroll across the top of the screen. Note that the message will vary depending on the problem.
- Whenever such a message appears, it is a good idea to write it down before doing anything else. This code contains information that will enable Bravis to deal quickly and easily with anything that requires their attention. With many of them you will be asked to contact Bravis Service and pass on the message, the model and the type of appliance.


### MESSAGE REPEATING

Push the FUNCTION button (2) then Key 1 (14) immediately after to repeat a message.



If no message repeats it means either the button combination was incorrect or the event has passed. Typical messages displayed advise of some appliance operations such as - "Pre-Wetting cooler pads - Please Wait!"

### SERVICE NOTIFICATION MESSAGE

When the operating hours logged for an appliance reach a predetermined duration, the spanner symbol  flashes once per second on the networker and a message displays, such as:

*Fan run hours indicate it is time for a service call - For assistance call 1300 555 545*

A service call may be booked.

### RESETTING

If something has interrupted the units operation, the word Reset (26) may appear beside Key 4 (17) while a message is scrolling. Press Key 4 (17) to re-start the Cooler.

If the Cooler does not resume normal operation, or the error message re-appears, contact Bravis Service.

If the Cooler is still operating but the Bravis Networker is showing an error message try pushing the Key 4 (17) to clear the fault. If the fault persists contact Bravis Service.

If the Cooler is not operating and any other error message appears, contact Bravis Service.

## LOCKING THE BRIVIS NETWORKER

To prevent any unwanted alterations being made to the coolers settings, the Brivis Networker can be locked via a 4- digit PIN code. In the case of dual Brivis Networkers, if one is locked the other is also locked.



If dual Brivis Networkers are installed, the user PIN codes can only be set at the Master Brivis Networker. The Slave Brivis Networker can only lock and unlock the system and cannot access the PIN codes.

### Setting the PIN

1. Press the FUNCTION button (2), followed immediately by Key 2 (15).  
The screen will then display *“Enter Your PIN number to lock the system”*.

**DO NOT ENTER NUMBERS AT THIS STAGE AND CONTINUE TO THE NEXT STEP.**

2. Push the MODE button (3).  
The screen will now display *“User PIN reset – Enter master PIN”*.

**DO NOT ENTER NUMBERS AT THIS STAGE AND CONTINUE TO THE NEXT STEP.**

3. Push the MODE button (3).  
The screen will now display the message *“User PIN number 1 alteration - Enter current PIN”*.

- If this is the first time for setting the PIN, the current PIN will be **“1111”**.
- If the PIN has been previously altered then enter your current PIN.  
The screen will then display the message, *“Enter the new PIN”*.

4. Enter your new 4-digit PIN number using a combination of Keys 1 to 5 (14 to 18).  
The screen will now display, *“Repeat the entry of the new PIN”*.  
Providing that you re-enter the new PIN correctly, the screen will now display *“Valid PIN – PIN altered”*.
5. If an incorrect number is entered press the AUTO key (6) to clear all digits, then re-enter your user PIN.
6. To exit this area at any time, just push the ON/OFF key (1).

### To Lock the Brivis Networker

1. Press the FUNCTION button (2), followed immediately by Key 2 (15).  
The screen will then display *“Enter Your PIN number to lock the system”*.
2. Enter your current user PIN to lock the Brivis Networker.  
The screen will now display *“System locked out!”*
3. If an incorrect number is entered press the AUTO key (6) to clear all digits, then re-enter your user PIN.



If an invalid PIN is entered, the message *“Invalid PIN entered - Try again”* will scroll across the screen. The user has three attempts at entering a valid PIN. On the third failed attempt the message *“Invalid PIN entered!”* will be displayed. At this point the Brivis Networker will abort the PIN entry screen, and return to its original state. You will then need to repeat the process.

A flashing Padlock icon (12) indicates that the Brivis Networker is locked.


### To Unlock the Brivis Networker

1. Press the FUNCTION button (2), followed immediately by Key 2 (15).  
The screen will then display *“Enter Your PIN number to unlock the system”*.
2. Enter your current user PIN to lock the Brivis Networker.  
The screen will now display *“System unlocked!”*
3. If an incorrect number is entered press the AUTO key (6) to clear all digits, then re-enter your user PIN.



If an invalid PIN is entered, the message *“Invalid PIN entered - Try again”* will scroll across the screen. The user has three attempts at entering a valid PIN. On the third failed attempt the message *“Invalid PIN entered!”* will be displayed. At this point the Brivis Networker will abort the PIN entry screen, and return to its original state. You will then need to repeat the process.

## NETWORKER WALL CONTROL OPERATION



### ZONING

Some systems may include multiple Coolers with each operating in a different zone area. Zone keys (28) will appear on the screen and these will have been set up and explained by the installer where required.

These zones can be operated in either “Manual” or “Auto” modes using the Zone keys - Keys 4 & 5 (17 & 18).


Two Zone keys will appear if you have three or four zones and only one Zone key will appear if you have one or two.

### DUAL BRIVIS NETWORKER OPERATION

It is possible to have two Bravis Networkers connected to the system. The two Bravis Networkers will operate together, one will be configured as a Master and the other as a Slave, and the settings for the Cooler will be common on both controllers. The benefit of having two controllers is the convenience of making adjustments to the Cooler settings at either location.

When an adjustment is made on one of the Bravis Networkers it is immediately reflected on the other Bravis Networker.

Likewise locking one of the Bravis Networkers also locks the other Bravis Networker. The system can be unlocked at either Bravis Networker.



**Please note:** This picture displays the lid closed. To reveal more keys flip down the lid from the top right hand corner.



**In Auto mode, only the Master Bravis Networker will sense the comfort level within the house.**

**Only the Master Bravis Networker has the ability to set the clock time. Look for the word Clock (30) beside Key 5 (18), while both the Bravis Networkers are in the off position.**

### BATTERIES

The Bravis Networker requires no batteries. If the Bravis Networker has no screen, check your 240 volt power supply (at the Cooler) or check the thermostat cable.



# PROGRAMMABLE CONTROL OPERATION

## OPERATING YOUR PROGRAMMABLE WALL CONTROL



This Wall Control gives the choice of Automatic or Manual modes with the option of a time ON or OFF delay.

### AUTOMATIC PRE-WET

When the cooler is turned on with both the fan and the pump, in either Auto or Manual mode, the cooler will start a Pre-Wet stage to ensure the pads are thoroughly wet before the fan starts. This contributes to the effective operation and performance of the cooler. The Pre-Wet time will vary depending on how long the cooler has been OFF, and whether it needs to fill the tank prior to operation.

### OPERATING MODES

The cooler has several operating modes, which are as follows:

1. Auto mode
2. Manual mode Fan and Pump
3. Manual mode Fan only
4. Manual mode Pump only.

Push the MODE key to cycle through the cooler's operating modes.



The wall control will remember previously established settings in Auto and Manual Modes.

### AUTO OPERATION

In AUTO mode the Programmable Wall Control automatically operates the cooler (fan speed and pump) to maintain the selected 'comfort level'. The cooler may even turn OFF if the conditions meet the comfort level setting.

### GETTING STARTED

Begin by pressing the On/Off key to turn the Cooler on. If the Auto light is illuminated, the system is set for Automatic operation, otherwise:

- Press the mode key to cycle through the Cooler's operating modes, until the Auto light is illuminated.
- Push the UP and DOWN keys to select the comfort level you require. The lower the number, the cooler the setting; the higher the number, the warmer the setting.

### BENEFITS OF USING IN AUTO MODE IN PREFERENCE TO MANUAL MODE

- Power and water consumption varies in relation to the chosen comfort level.
- This comfort level cannot be as easily maintained in Manual mode.
- In auto mode the unit operates only when it is required.
- Enables a set comfort level to be maintained automatically as the outdoor/indoor temperature conditions change.
- Allows you to pre-set the cooler to turn ON early and not let the house build up heat.
- The outlet airflow noise is kept to a minimum, as the fan speed is only as fast as required to maintain the set comfort level. This slower speed also results in more efficient saturation of the cooler filter pads, and a cooler outlet air temperature.

### MANUAL OPERATION

Manual operation requires you to manually control the fan, its speed, and the pump.

### GETTING STARTED

Begin by pressing the ON/OFF key to turn the Cooler on. For Manual operation the AUTO light must not be illuminated.

Push the MODE key to cycle through the cooler's operating modes.

### FAN AND PUMP

This is indicated by the illuminated Fan and Pump lights. The screen will then display a number, which indicates the cooler fan speed.

Push the UP and DOWN keys to raise and lower the cooler's fan speed.



The fan light will flash during the Pre-Wet period.

### FAN ONLY

This is indicated by the illuminated FAN light. The screen will then display a number, which indicates the cooler's fan speed.

Push the UP and DOWN keys to raise and lower the cooler's fan speed.



On days of high humidity the fan may be operated without the pump. For ventilation only, operate the cooler in this mode.

### PUMP ONLY

This is indicated by the illuminated PUMP light. Only the pump will be running in this mode, and no air will be circulating.

### USING THE TIMER


This wall control has a timer function that can delay the operation of the ON/OFF key. If the cooler is operating, you can pre-set the timer for the cooler to turn Off. If the cooler is off you can pre-set the timer for the cooler to turn On. The timer is set in 1-hour increments, ranging from 1 to 12 hours. When setting the timer to turn the cooler on, the wall control returns to the settings it had when it last operated. To check or adjust these settings turn the wall control on, make any adjustments if necessary, then turn the wall control off and set the Timer. When setting the timer to turn the cooler off, have the cooler running at your desired settings and set the timer.

### SETTING THE TIMER

- Press the TIMER key to enter the timer setting mode. The timer light will now be flashing and the screen will display a number.
- Push the UP and DOWN keys to set the delay in hours. The timer delay can only be adjusted while the timer light is flashing.
- To cancel the timer push the TIMER key twice or push the ON/OFF key.
- After the timer has been set, leave the controller for five seconds until the timer light stops flashing.

# MANUAL WALL CONTROL OPERATION

## OPERATING YOUR MANUAL WALL CONTROL



The Manual Wall Control requires you to manually control Pump (and Pre-Wet cycle) operations, fan operation and the fan speed. On days of high humidity for ventilation the fan may be operated without operating the pump.

### To run the Cooler

1. Push the ON/OFF button (1) to turn the controller ON, the Power indicator (2) will illuminate.
2. Slide the COOL switch (3) to the ON position. This will operate the pump.



**After sliding the COOL switch (3) ON allow 5–10 minutes to Pre-Wet the filter pads before sliding the FAN switch (4) ON. Doing this will provide for the maximum cooling immediately when the fan is switched ON.**

3. Slide the FAN switch (4) to the ON position.
4. Rotate the FAN SPEED dial (5) to set the desired airflow level.

### To turn OFF

1. Push the ON/OFF button (1) to turn the controller OFF, the Power indicator (2) will go out.

### To run the Fan for ventilation

1. If already cooling, slide the COOL switch (3) to the OFF position, this will turn off the pump and use the fan for ventilation only.

### OR

1. When OFF, push the ON/OFF button (1) to turn the controller ON, the Power indicator (2) will illuminate.
2. Slide the Fan switch (4) to the ON position.
3. Rotate the Fan Speed dial (5) to set the desired airflow level.



**On days of high humidity the fan may be operated without the pump. For ventilation only, turn the Cool switch OFF which turns the pump OFF.**

# CARE & MAINTENANCE

## COOLER SERVICE & MAINTENANCE

To ensure that your Brivis cooler continues to operate at peak efficiency, it should be serviced at two year intervals by an authorised person trained in the service of Brivis coolers - please contact our National Care Centre, for authorised Brivis Service Technicians. Refer to the back of this manual for contact details.

This service of the cooler unit will include all maintenance and adjustments required to the following components to ensure your cooler runs at its peak efficiency:

- Trough
- Electronic Controls e.g. Sensors
- Fan and Pump Assembly
- Pads and Water Distribution



**Please note that to maintain your warranty, the above servicing needs to be conducted by an authorised person trained in the service of Brivis Coolers. Please contact our Brivis Service Department for an authorised Brivis Service Technician.**



**Service maintenance is not covered under warranty and is a chargeable service. All coolers must have safe and reasonable access and be installed in compliance with the installation instructions supplied with the unit. Some installations may require two service personnel to attend, in accordance with Health & Safety requirements.**

## SAVE A SERVICE CALL

Service calls can often be avoided! If you feel your cooler is not operating properly, please check these possible causes first:

### General Troubleshooting

- Check the water supply to the unit is turned ON.
- Ensure the pump is operating and visually check the pads for even water distribution.
- Check that the number of doors and windows open is sufficient within the targeted cooling area. Too many or not enough doors and windows opened in the targeted area could result in inadequate ventilation. This could result in poor cooling performance.
- Check that the fan operates and air is coming out from the duct outlet.
- Check that the filter pads are not damaged and/or the material hasn't deteriorated.
- If external weather conditions are excessively humid, the cooler may not perform at its optimal cooling level.

### If the fan will not start.

- Check if the power is ON.
- Check if the Wall Control is turned ON, and set the comfort level that requires the Cooler fan to operate.
- Check that the fan is not in Time Delay Mode caused by: pre-programmed times for the ServoSeal damper (Brivis Contour Series only) and motorised drain to open, the Cooler's tank to fill with water, or a pre-wet of the filter pads.
- Check the fuse in the meter box.



**The usual time delay can be up to 8 Minutes.**

### The unit will not turn on

- Check the circuit breaker has not been tripped - if so reset it. Reset the Cooler at the power supply.

### The unit is blowing warm air

- Check the water supply tap is turned on at the unit. Check the pump has been selected on the wall control

### An error message is appearing on the Brivis Networker

- Refer to the section on "Coded Messages" on page 14 and follow the checks. Check the power point is plugged in and turned on to the Cooler.

### The Brivis Networker display is blank

- Check there is power to the power point with another appliance. Check the circuit breaker has not been tripped - if so reset it.

**The unit is not cooling very well**

- Check the water supply tap is turned on at the Cooler
- Check the pump has been selected on the wall control.
- Check sufficient door and/or windows have been opened. Refer to exhaust requirements covered in "Before Operating Your Evaporative Cooler" on page 8.

**There is no air coming out of some vents**

- Contact our service department to place a service call.

**There is moisture on my tiles**

- Check the vents are directing air flow across the ceiling and not towards the floor. If it is humid turn the pump off.
- Check sufficient door and/or windows have been opened. Refer to exhaust requirements covered in "Before Operating Your Evaporative Cooler" on page 8.

**The padlock is appearing on the screen**

- This indicates that the child proof lock has been activated. Refer to the section on "To Unlock the Brivis Networker" on page 15.

**INSTALLATION RECORD**

***Installer Details***

Installers Name: \_\_\_\_\_

Company Name: \_\_\_\_\_

Company Address: \_\_\_\_\_  
 \_\_\_\_\_  
 \_\_\_\_\_

**Company Contact Details**

Telephone: \_\_\_\_\_

Mobile Phone: \_\_\_\_\_

Certificate of Compliance / Certification Number: \_\_\_\_\_

Authorised Persons - Licence Number: \_\_\_\_\_

Installers Signature: \_\_\_\_\_

Installation Date: \_\_\_\_\_

***System Details***

Model Number : \_\_\_\_\_

Serial Number: \_\_\_\_\_

**SERVICE MAINTENANCE SCHEDULE**

Your ducted evaporative cooler should be serviced at two-year intervals after the date of installation by a qualified licensed technician in accordance with the Schedule below. Failure to do so during the product warranty period may void your warranty. This periodic service and maintenance will prolong the useful life of the unit, and help keep it running safely and at optimum efficiency.

Date of Installation	/	/	Installed By:			
YEAR OF SERVICE	2	4	6	8	10	12
Service Date	/	/	/	/	/	/
Service Company / Technician						
<b>ELECTRICAL</b>						
Wiring						
Fan Motor						
Fan Motor Capacitor						
Printed circuit boards						
Water Pump						
Inlet Solenoid						
Damper Motor (if applic)						
<b>WATER DISTRIBUTION</b>						
Pump and associated fittings						
Water distribution pipework						
Water management system (if applic)						
Drain Valve						
Water Supply Line						
Bleed rate setting (if applic)						
Water reservoir						
Cooling pads						
<b>MAJOR COMPONENTS</b>						
Fan						
Cabinet						
<b>CONTROLS</b>						
Wall control						
<b>GENERAL OPERATION</b>						
Pad saturation						
Water level						
Water fill						
Water drain						
Winter Seal (if applic)						
<b>GENERAL INSTALLATION-RELATED AND 3rd PARTY COMPONENTS (NOT BRIVIS PRODUCTS) *</b>						
Airflow thru system						
<b>CONSUMABLES**</b>						
Fan Capacitor						
Fan Collet						
Snorkel						
Hoses						
O-rings						
Pads (after fifth year)						
Water level sensor						
* Installation and other field-supplied components are not covered by Brivis Product Warranty. These include, but are not limited to, control wiring, ducting, diffuser, controls/thermostats, pipework and fabricated or added components and water and electrical connections to the appliance. These should be inspected as they can affect the performance, reliability and safety of the cooler. ** Units contain consumable items that may require periodic replacement and are not covered by Brivis product warranty (e.g. filter pads, capacitors, hoses, O-rings)						
<b>ACTION CODES</b>						
Inspected - Working Correctly - No Action Required	Adjusted Part	Cleaned Part	Replaced Part	Repaired Part	Referred to Installer	
✓	A	C	R	RP	RI	

**Q.** How often should the cooler be serviced?

**A.** Brivis recommend the cooler is serviced every 2 years at a minimum to ensure it operates at peak efficiency.



**Please Note: Due to environmental conditions the cooler may need to be serviced every year.**

**Q.** What is done in a service?

**A.** Our comprehensive service plan designed to maintain your cooler includes.

- Check filter pad material for holes or deterioration. The pads will deteriorate over time and lose their water absorption ability. Replace pads as required.
- Clean the tank and internal surfaces.
- Clean the filter pads and flush with water.
- With the filter pads in position, switch ON the power supply isolating switch and operate the unit.
- Ensure the pump is operating, and visually check the pads externally for even water distribution.
- Ensure the water inlet is operating correctly.
- Ensure the water system is operating to the minimum and maximum water levels.
- Check that the water supply pressure is sufficient to fill the tank within the allotted time.
- Check the fan operates, and varies speed between the minimum and maximum setting on the Wall Control.
- Check and lubricate all moving parts.
- On Brivis Contour Series and some Advance Series models, ensure the ServoSeal damper mechanism is opening and closing correctly.



**Please note that to maintain your warranty, the above servicing needs to be conducted by an authorised person trained in the service of Brivis Coolers.**

**Q.** I own a Brivis AD cooler - Why is water continually running while the unit is on?

**A.** All Brivis AD models use the “bleed off” method for tank water quality control. This “bleed off” will continually rid the cooler of any salt or sediments and allow for the tank to be continually topped up with clean water.

**Q.** I own a Brivis Advance or Brivis Promina cooler - Why does the unit dump water periodically during operation?

**A.** Brivis Advance and Brivis Promina coolers use the “Running Refresh” method for tank water quality control. This “Running Refresh” ensures that the salt or sediments accumulating in the cooler do not exceed an acceptable level by periodically flushing the tank while the cooler is operating.

**Q.** The air smells a little different. Why?

**A.** New Cooling pads can give off a mild odour while they are settling in. This is quite normal, it will dissipate quickly as the new pad is constantly flushed during use. It may also be indicating that the unit requires a service.

**Q.** How much water does my evaporative cooler use?

**A.** The amount of water an evaporative cooler uses is dependant on the evaporation rate of the coolers pads.

The more water the cooler can evaporate for a given condition and airflow, the more cooling potential the cooler has.

The evaporation rate varies depending on the current weather conditions, the size of the cooler, the speed of the coolers fan or the velocity of the air through the pads, and the condition and type of the filter pad material.

In addition to the cooler evaporating water, water is also displaced to maintain the water quality within the cooler so that the coolers pads and other components do not deteriorate prematurely.

**Q.** Can I run the system when I am not home?

**A.** Evaporative cooling relies on doors and/or windows being open so you can run it when you are not home, provided you have the required ventilation openings.

**Q.** How much water does the tank of my cooler hold?

Model		Tank Capacity (litres)
Brivis Contour Series	L37, L47, L57, L67, L77	12
Brivis Promina	P36, P46, P56, P66, P76	12
Brivis Advance Series	F36DS, F46DS, F56DS, F66DS, F76DS, F86DS	15
Brivis AD	AD56DBAL, AD66D/BAL, AD86D	32

**Q.** How many doors and windows should I have open?

**A.** Refer to the section on openings required. The table gives a guide to the amount of opening area required for each model in m<sup>2</sup>, and also gives suggestions on how to provide this.

**Q.** Why is there condensation and moisture on my tiles?

**A.** Make sure the vents are directed across the room and not towards the floor. Make sure sufficient doors and windows are open. Refer to the section on openings required. If it is a humid day turn the pump off.

**Q.** There is no air coming out of some of the vents

**A.** It is highly probable that this is an installation issue. Please contact your installer in the first instance.

**Q.** What does duct cleaning entail?

**A.** Like any other part of your home dirt, dust and other foreign particles can accumulate and breed in the ductwork and on system diffusers.

- Remove dust from your cooling system
- Kill any potential dust mites living & breeding throughout your cooling system
- Remove odours from your cooling system
- Helps improve indoor air quality
- Allergy sufferers may benefit from clean ducts
- Clean the Cooler fan and assembly
- Clean the Supply air diffusers

**Q.** Can I run heating through the same ductwork as my evaporative cooler?

**A.** No, the differing technology between ducted heating and evaporative cooling doesn't allow the units to share the same ductwork. Also, evaporative cooling requires larger ductwork for airflow.

**Q.** How far should my cooler be away from sanitary vents?

**A.** The unit should be at least a 5 metre radius away from a sanitary outlet.

**Q.** How cool is cool?

**A.** The degree of cooling available from any type of air conditioning, is dependent on the outside weather conditions. Your Evaporative Cooler works best on hot, dry days. After all, that's when you require the most relief.

**Q.** Should the unit have its own circuit in the meter box?

**A.** Yes, we recommend the power socket is wired back to the meter box on a dedicated power circuit.

**Q.** Should water be coming out of my evaporative cooler during operation?

**A.** Brivis Advance and Brivis Promina Series models will complete a flush service approximately every 20 cycles of the pumps operation. This means you will see the unit dump the water out of the overflow pipe.

Brivis Contour Series models will not dump any water during operation as they are fitted with an AquaSave which operates to keep the water clean.

Brivis AD models will have a small continuous flow from the drain outlet.

**Q.** Why doesn't my evaporative cooler turn on when the current time and room temperature is displayed yet the word 'COOLER' is not?

**A.** Your evaporative cooler has lost communication with your Networker Wall Controller, a service call is required.



- Q.** We have a unit with a Networker Wall Controller. How is the LED screen backlight activated without changing any setting? Is there one key to press that activates the backlight without affecting the current controller function?
- A.** The LED backlit screen can be activated by pressing the Function key (Fn button).
- Q.** The system is ON and there is no air coming out of any vents.
- A.** If you have a unit with a Networker Wall Controller, error 60 may display. Turn power to the cooler off and on at switchboard in an attempt to initiate a system reset, if this fails a service call is required.

# WARRANTY

## TERMS OF WARRANTY – AUSTRALIA

Rinnai Australia Pty. Ltd. ABN 74 005 138 769, 100 Atlantic Drive, Keysborough VIC 3173.

### NOTICE TO CONSUMERS UNDER AUSTRALIAN CONSUMER LAW

Our goods and services come with guarantees that cannot be excluded under the Australian Consumer Law.

For a major failure with a good, you are entitled to a replacement or refund and compensation for any other reasonable foreseeable loss or damage. If the failure does not amount to a major failure and if the goods fail to be of acceptable quality, you are also entitled to have the goods repaired or replaced.

For a major failure with the service, you are entitled to cancel your service contract with us and obtain a refund for the unused portion, or to compensation for its reduced value. You are also entitled to be compensated for any other reasonably foreseeable loss or damage. If the failure does not amount to a major failure you are entitled to have problems with the service rectified in a reasonable time and, if this is not done, to cancel your contract and obtain a refund for the unused portion of the contract.

The benefits provided by this Warranty are in addition to any other rights and remedies available to a consumer under the Australian Consumer Law and any other law which may apply to the goods and or services.

## 1 DEFINITIONS

The terms listed below shall have the following meanings:

- 1 **“Authorised Service Representative”** means an independent service contractor authorised by Rinnai or Rinnai service personnel.
- 2 **“Rinnai”** means Rinnai Australia Pty Ltd (ABN 74 005 138 769) and any related company.
- 3 **“Certificate(s) of Compliance”** means certificate(s) issued by licensed personnel (including plumbers, refrigeration mechanics, electricians or other relevant tradespeople) to certify that any prescribed works comply with applicable regulatory requirements.
- 4 **“Certificate(s) of Occupancy”** means certificate(s) issued by the local government authority (or similar organisation) which certifies that a home can be occupied.
- 5 **“Installation Site”** means the site at which the Product is originally installed.
- 6 **“Normal Business Hours”** means 8:30am to 5:00pm Monday to Friday, excluding public holidays.
- 7 **“Operating/Installation Instructions”** means the user manual or other documentation which provides detailed instructions on the proper operation and maintenance of the Product.
- 8 **“Other Applications”** means any Product used for purposes other than Residential & Light Commercial Applications. Other Applications may include but are not limited to factory, IT/Server room, telephone exchange, processing area (e.g. bakery, kitchen, warehouse, swimming pool, agricultural facilities such as a nursery). Any Product which has been installed, for whatever purpose, as a retrofit component to an existing system, will also be classed as being part of an “Other Application” regardless of the purpose of use of the existing system into which such product has been installed.
- 9 **“Purchaser”** means the end user of the Product, the person named as owner in the Warranty certificate, the holder of the Proof of Purchase or the holder of a property transfer document where the Product is included as part of the chattels.
- 10 **“Product”** means the equipment purchased by the Purchaser and described in Section 2 of this document.
- 11 **“Proof of Purchase”** means a Tax Invoice or Receipt in respect of the Product. In the case of new constructions, a Certificate of Occupancy or a Certificate of Compliance that details the date of installation or commissioning will suffice.
- 12 **“Qualified Installer”** means the qualified installation contractor who is responsible for performing the installation work in the manner prescribed by local and statutory regulations, including compliance with any relevant and to Rinnai specifications, including Australian Standards.
- 13 **“Residential & Light Commercial Applications”** means any Product for use in residential or light commercial applications where
  - a) the Product is solely used for the purpose of human comfort; and
  - b) the ambient temperature of the space the Product is intended to heat or cool is influenced solely or primarily by natural exterior weather conditions rather than by man-made or mechanical heat sources.

Examples of Residential & Light Commercial Applications include, homes, offices, hotels, apartments, nursing homes, hospitals, health care premises, shopping centres, and retail stores.

## 2 TERMS OF WARRANTY

- 2.1 Subject to the Terms of Warranty set out in this document, effective from the date of purchase by the Purchaser, the Product is warranted to be free from defects in materials & factory workmanship for the period set out in table below:

	PRODUCT GROUPS	PARTS	LABOUR
Residential and Light Commercial	Evaporative Coolers & Ducted Gas Heaters (excluding Compact Classic Series)	5 Years *Extended 4 Years Option	5 Years *Extended 4 Years Option
	Ducted Gas Heaters - Compact Classic Series	3 Years	3 Years
	Refrigerated Airconditioning Products	5 Years	5 Years
	Ducted Gas Heaters - Heat Exchangers and Burners Evaporative Coolers - Structural components only	10 Years	N/A
	Portable Air conditioning	2 Years	N/A
	Wi-Fi Devices	1 Year	1 Year
Other Applications	All Product Groups	2 Years	1 Year
After Market	Spare Parts	1 Year	N/A
*Extended Warranty Option	Up to 4 year extended warranty (in addition to the standard warranty period listed above) applies on selected products when you opt in to the Rinnai Service Advantage program. This program has terms and conditions, including the requirement for scheduled servicing of the product by Rinnai. To participate in the program you must register your product online at: <a href="http://www.rinnai.com.au/support-resources/warranty-registration/">www.rinnai.com.au/support-resources/warranty-registration/</a> within the first 12 months of the product being installed.		

- 2.2 Rinnai will determine in its sole discretion, which classification the Product fits into and the corresponding Warranty that shall apply.
- 2.3 An Authorised Service Representative will repair or replace, at its option, the Product or any part of the Product that its examination shows to be defective. The repair or replacement shall be performed during Normal Business Hours by an Authorised Service Representative. Repair by persons other than an Authorised Service Representatives may void the Warranty.
- 2.4 Alternatively to clause 2.3 above, Rinnai can at its discretion elect to pay you an amount equivalent to the cost of repairing or replacing the Product.
- 2.5 If Rinnai provides you with either the replacement costs or replacement product, ownership of the original Product shall immediately transfer to Rinnai.
- 2.6 Rinnai is responsible for reasonable costs associated with legitimate warranty claims, including call-out of an Authorised Service Representative to inspect the Product. Rinnai is not responsible for:
- costs for tradespeople engaged by you that are not Rinnai Authorised Service Representatives.
  - any costs, including call out costs for a Rinnai Authorised Service Representatives, associated with a Product which is determined upon inspection not to be covered by this warranty.
- 2.7 Rinnai will reimburse any reasonable costs associated with making a legitimate warranty claim against Rinnai which are not otherwise specified above.
- 2.8 The Warranty of the Product requires that, in addition to all other conditions, the Purchaser conducts regular and/or preventative maintenance as may be specified by the Operating/Installation Instructions or otherwise directed by Rinnai and required by the level of usage and the usage environment, including the use of correct and uncontaminated refrigerants and lubricants. Refrigeration, plumbing and electrical works must be undertaken by licensed personnel.
- 2.9 Where a Product or failed component is replaced under warranty, the time remaining on the original Product warranty period will continue to apply and the replacement product or part will be subject to the original warranty period only.

**3 CONDITIONS OF WARRANTY**

- 3.1 The Purchaser may only obtain the benefit of the Warranty if the Purchaser:
- a) maintains and has the Product serviced in accordance with the instructions set out in the service section of the relevant Service or Owner's Manual;
  - b) complies with clause "7 Purchaser's Responsibilities" on page 29;
  - c) notifies Rinnai within 30 days of a defect occurring or, in the case of a latent defect, becoming apparent, that a claim is being made under this Warranty; and
  - d) provides, in support of the claim made under this Warranty, a Proof of Purchase.
- 3.2 This document (and any statutory consumer guarantees) represents the only Warranty given by Rinnai in respect of the Product. No other person or organisation is authorised to offer any alternative warranty on behalf of Rinnai.
- 3.3 If the date of purchase cannot be established to Rinnai's satisfaction, the date shall be deemed to be 2 months after the date of manufacture or the date of sale by Rinnai, whichever is the latter.
- 3.4 This warranty applies to Products which are manufactured on or after the date of publication of this warranty but before the next date of publication of this warranty.

**4 EXCLUSIONS**

- 4.1 This Warranty **does NOT** cover:
- a) damage, problems or failure resulting from improper operation and/or inadequate maintenance by the Purchaser (refer Purchaser's Responsibilities section below);
  - b) damage, problems or failure resulting from improper or faulty installation. The Product must be installed by a Qualified Installer in accordance with applicable regulations. Where applicable, Certificate(s) of Compliance must be obtained by the purchaser from the Qualified Installer and presented to the Authorised Service Representative;
  - c) damage, problems or failure caused by factors external to the Product including, but not limited to, faulty or poor external electrical wiring, incorrect or faulty power supply, voltage fluctuations, over voltage transients or electromagnetic interference, inadequate or faulty gas, drainage services, or water services, including water pressure, and non-potable water;
  - d) damage, problems or failure caused by acts of God, fire, wind, lightning, flood, storm, hail storm fallout, vandalism, earthquake, war, civil insurrection, misuse, abuse, negligence, accident, pests, animals, pets, vermin, insects, spiders/bugs or entry of foreign objects or matter into the Product such as dirt, debris, soot or moisture;
  - e) damage, problems or failure caused by environmental conditions including, but not limited to, excessive moisture, salt or other corrosive substances or atmospheric conditions;
  - f) Product which has been installed in a portable or mobile building, structure or application including, but not limited to, a caravan, boat or trailer;
  - g) Product which has been re-installed at a location other than the original site;
  - h) any consumable item supplied with the Product including, but not limited to, an air filter, battery, fan belt, igniter or cooler pad;
  - i) installation of third-party components that may be attached to the Product. These include, but are not limited to, control wiring, ducting, return air filter(s) grille, register, diffuser, zone motors, controls/thermostats, pipe work and fabricated or added components. These items remain solely the responsibility of the Qualified Installer;
  - j) installations where electrics/electronics may be subjected to moisture/chemicals (e.g. swimming pools or nurseries);
  - k) any repair, which is needed as a result of an accident, misuse, abuse or negligence;
  - l) Product that is utilised in an environment (indoor and outdoor) outside its specified operating range; and
  - m) fair wear and tear to the Product.
  - n) On-site labour warranty on portable (non-fixed installation) Products – In respect of such Products the Purchaser must return the Product to the supplier for repair or replacement).

## 5 LIMITATIONS

- 5.1 Third parties are often involved in providing advice to consumers about the climate control solutions best suited to the consumer's needs. Any advice or recommendations given by such parties, including advice about Product fitness for purpose and overall system design, sizing and application are not the responsibility of Rinnai. This includes but is not limited to the heat load calculations, airflow and system balancing.
- 5.2 This Warranty does not apply to any Product installed at an Installation Site which is outside Australia.
- 5.3 Except where inconsistent with the purchaser's statutory rights and the rights given by this Warranty, all liabilities of Rinnai for any direct, special, indirect or consequential loss or damage, any damage or expense for personal injury or any loss or destruction of property, arising directly or indirectly from the use or inability to use the Product or any of its parts and/or servicing the Product, are expressly excluded.

## 6 TRAVEL, TRANSPORT & ACCESS COSTS

- 6.1 The Purchaser must pay freight charges, in-transit insurance expenses and travelling costs for repairs/replacements under this Warranty, that are required to be performed 50km from the nearest Rinnai branch or Authorised Service Representative.
- 6.2 Subject to clause 6.3, Rinnai will pay freight charges, in-transit insurance expenses and travelling costs for repairs/replacements that are required to be performed less than 50km from the nearest Rinnai branch or Authorised Service Representative, subject to the following:
- a) Rinnai will arrange for such repairs/replacements and make any payment directly to the third party to provide the freight, in-transit insurance or travel services; or
  - b) if Rinnai considers appropriate, it will authorise the Purchaser in writing to pay for the relevant freight charges, in-transit insurance expenses or travelling costs and then, upon provision by the Purchaser to Rinnai of a tax invoice showing those costs have been incurred, reimburse the Purchaser for such costs which are within the terms of the authorisation. If the Purchaser pays for the relevant freight charges, in-transit insurance expenses or travelling costs without written authorisation from Rinnai, Rinnai will not reimburse the Purchaser for such costs.
- 6.3 The Purchaser must pay all costs and expenses in respect of:
- a) any service call out fee if the Product is not accessible for service
  - b) making the Product accessible for service, for example, restricted access or working at heights, or the labour cost for an additional person due to OHS requirements.
  - c) providing a safe working environment for installation, service, maintenance or repair of the Product;
  - d) any surcharge applicable in respect of supplying replacement parts outside Normal Business Hours; and
  - e) any other costs and expenses in relation to claiming the Warranty that is not covered by clause 6.2.

## 7 PURCHASER'S RESPONSIBILITIES

- 7.1 The Purchaser must operate and maintain the Product in accordance with the Operating Instructions and service maintenance schedule, including conducting an appropriate number of services to the unit during the Warranty period, based on usage and the usage environment including but not limited to;
- a) regularly cleaning the air filter(s) and replacing them where necessary;
  - b) replacing expired batteries or other consumables as required;
  - c) ensuring that the condensate drain is kept clean and clear of obstructions.

### HOW TO MAKE A WARRANTY CLAIM:

If you wish to make a warranty claim in respect of any Portable Product, please return it to the place of purchase, or if that is not possible, contact Rinnai to enquire about alternative arrangements.

If you wish to make a warranty claim in respect of any fixed Product, please contact Rinnai on the details set out below to make arrangements for an Authorised Service Representative to inspect the product.

As per clause 2.6 of the Terms and Conditions of Warranty, purchasers are responsible for the costs of any repair and/or call out fee where, on inspection, the alleged defect is found by Rinnai's Authorised Service Representative not to be covered by this warranty or any statutory consumer guarantee applicable to the Product.

The Terms and Conditions of Warranty contain important information about your rights and obligations under this warranty. Please read them fully and carefully before making a claim.

# NOTES





# Rinnai Australia Pty Ltd

ABN 74 005 138 769 | AU45204

100 Atlantic Drive, Keysborough, Victoria 3173  
P.O. Box 460, Braeside, Victoria 3195  
Tel: (03) 9271 6625  
Fax: (03) 9271 6622

## **National Help Line**

Tel: 1300 555 545\* Fax: 1300 555 655  
*Monday to Friday, 8.00 am to 5.00 pm EST.*

*\*Cost of a local call higher from mobile or public phones.*

For further information visit [www.rinnai.com.au](http://www.rinnai.com.au)  
or email [enquiry@rinnai.com.au](mailto:enquiry@rinnai.com.au)

Rinnai has a Service and Spare Parts network with personnel who are fully trained and equipped to give the best service on your Rinnai appliance. If your appliance requires service, please call our National Help Line. Rinnai recommends that this appliance be serviced every 2 years.

With our policy of continuous improvement, we reserve the right to change, or discontinue at any time, specifications or designs without notice.